



HOW TO USE THE WASHING MACHINE

- **One Token buys exactly One Wash at Programme Number 4 at 40°C including detergent and drying rack. Use only this programme and temperature!**
- **Wash programme number 4 takes one hour and 35 minutes from start to finish.**
- **One hour and 40 minutes must have elapsed between inserting one token and inserting the next.**
- **The maximum acceptable washing load is 4.5 kg - overloading the washer results in damage to the machine and a bad wash.**
- **The on-off switch must be pressed-out at the end of the cycle before the door-lock will release. If the door remains locked don't force (and break) the door button. Call Paul or Luca!**

COME USARE LA LAVATRICE

- **Un gettone da diritto ad una lavata al programma 4 a 40°C incluso il detersivo e lo stendipanni. Usare esclusivamente il programma e la temperatura indicati!**
- **Il programma di lavaggio 4 dura 1 ora e 35 minuti dall'inizio alla fine.**
- **Bisogna aspettare 1 ora e 40 minuti tra l'inserimento di un gettone e del successivo.**
- **Il Massimo carico accettabile per la lavatrice è di 4,5 Kg - sovraccaricare la macchina ne causa il danneggiamento e un inefficace funzionamento.**
- **Il pulsante on-off deve essere su off (in fuori) al termine del ciclo di lavaggio e prima che il blocco dello sportello ne consenta l'apertura. Se lo sportello rimane bloccato non sforzare (e rompere) il pulsante di apertura. Chiamate Paul o Luca!**